

# OAV Air Bearings

## How do Air Bearings Work?

Air bearings are designed to lift loads away from the surface and float them on a thin film of air. Air bearings use a thin film of pressurized air to support a load. There is no Solid contact between the two surfaces.

Unique solution ID: #1002

Author: oav air bearings

Last update: 2014-09-03 22:18